

TMATS Basics

Everything you need to know in 30 minutes

References


- IRIG 106-19 Chapter 9 -
https://www.wsmr.army.mil/RCCsite/Documents/106-19_Telemetry_Standards/Chapter9.pdf
- IRIG 124-19 TMATS Handbook
https://www.wsmr.army.mil/RCCsite/Documents/124-19_TMATS_Handbook/124-19_TMATS_Handbook.pdf

Note: click cancel if username/password box appears

Groups

Identifier	Title
G	General Information
T	Transmission Attributes
R	Recorder-Reproducer Attributes
M	Multiplex/Modulation Attributes
P	PCM Format Attributes
D	PCM Measurement Description
B	Bus Data Attributes
S	Message Data Attributes
C	Data Conversion Attributes
H	Airborne Hardware Attributes
V	Vendor-Specific Attributes
X	TMATS eXtension Attributes

Structure



G Group

Figure 9-2. General Information Group (G)		Code Name
PROGRAM NAME - 9-10		(G\PN)
9-10	TEST ITEM	(G\TA)
	*Information	
	TMATS FILE NAME	(G\FN)
	RCC IRIG 106 REVISION LEVEL	(G\106)
	ORIGINATION DATE	(G\OD)
	REVISION NUMBER	(G\RN)
	REVISION DATE	(G\RD)
	UPDATE NUMBER	(G\UN)
	UPDATE DATE	(G\UD)
	TEST NUMBER	(G\TN)
	NUMBER OF POINTS OF CONTACT	(G\POC\N)
9-10	*Point of Contact	
	NAME	(G\POC1-n)
	AGENCY	(G\POC2-n)
	ADDRESS	(G\POC3-n)
	TELEPHONE	(G\POC4-n)
9-11	*Data Source Identification	
	NUMBER OF DATA SOURCES	(G\DSIN)
	DATA SOURCE ID	(G\DSI-n)
	DATA SOURCE TYPE	(G\DST-n)
	DATA SOURCE SECURITY CLASSIFICATION	(G\DSC-n)
9-12	*Test Information	
	TEST DURATION	(G\TI1)
	PRE-TEST REQUIREMENT	(G\TI2)
	POST-TEST REQUIREMENT	(G\TI3)
	SECURITY CLASSIFICATION	(G\SC)
9-13	*TMATS Checksum	
	MESSAGE DIGEST/CHECKSUM	(G\SHA)
9-13	* Comments	
	COMMENTS	(G\COM)
*Heading Only - No Data Entry		

G Group Example

G\PN:PIT-PCM;
G\TA:PIT(15-001)P121;
G\106:09;
G\FN:C:\TMP\VM_121\D200F Recorder PCM1_PCM2.tmt;
G\DSI\N:1;
G\DSI-1:DATASOURCE;
G\DST-1:DRS;
G\OD:10-02-2018;
G\UD:09-18-2004;
G\POC\N:1;
G\POC1-1:ILIAD HeimRecorderGen;
G\COM:Generated by ILIAD Unit Generator build 802.17.0.184 on 2018/10/02 13:31:08;

M Group

Figure 9-5. Multiplex/Modulation Attributes Group (M)			Code Name
DATA SOURCE ID - 9-85			(M-x\ID)
9-85	*Composite Signal Structure		
		SIGNAL STRUCTURE TYPE	(M-x\BB1)
		MODULATION SENSE	(M-x\BB2)
		COMPOSITE LPF BANDWIDTH	(M-x\BB3)
9-85	*Baseband Signal		
		BASEBAND SIGNAL TYPE	(M-x\BSG1)
	*Low Pass Filter		
		BANDWIDTH	(M-x\BSF1)
9-86		TYPE	(M-x\BSF2)
	*Baseband Data Link Type		
	*PCM		
	OR	DATA LINK NAME	(M-x\BB\DLN)
9-87	*Analog		
		MEASUREMENT NAME	(M-x\BB\MN)
	*Subcarriers		
		NUMBER OF SUBCARRIERS	(M-x\SCO\N)
9-87	*IRIG Subcarriers		
		NUMBER OF SCOs	(M-x\SIN)
		SCO NUMBER	(M-x\SI1-n)
		SCO #n DATA TYPE	(M-x\SI2-n)
9-87		MODULATION SENSE	(M-x\SI3-n)
	*Low Pass Filter		
		BANDWIDTH	(M-x\SIF1-n)
		TYPE	(M-x\SIF2-n)
9-88	*Data Link Type		
	*PCM		

M Group Example

```
COMMENT:=====;
COMMENT:      PIT-PCM_1;
COMMENT:      PCM1;
COMMENT:=====;
M-1\ID:PCM1;
M-1\BSG1:PCM;
COMMENT:=====;
COMMENT:      PIT_WDAU,0,WDAU-2016-1;
COMMENT:      PCM1;
COMMENT:=====;
M-1\BB\DLN:PCM1;
```


P Group

Figure 9-6. PCM Format Attributes Group (P)			Code Name
DATA LINK NAME - 9-93			(P-d\DLN)
9-93	*Input Data		
		PCM CODE	(P-d\D1)
		BIT RATE	(P-d\D2)
		ENCRYPTED	(P-d\D3)
		POLARITY	(P-d\D4)
		AUTO-POLARITY CORRECTION	(P-d\D5)
		DATA DIRECTION	(P-d\D6)
		DATA RANDOMIZED	(P-d\D7)
		RANDOMIZER LENGTH	(P-d\D8)
9-95	*Format		
		TYPE FORMAT	(P-d\TF)
		COMMON WORD LENGTH	(P-d\F1)
		WORD TRANSFER ORDER	(P-d\F2)
		PARITY	(P-d\F3)
		PARITY TRANSFER ORDER	(P-d\F4)
		CRC	(P-d\CRC)
		CRC CHECK WORD STARTING BIT	(P-d\CRCCB)
		CRC DATA START BIT	(P-d\CRCDDB)
		CRC DATA NUMBER OF BITS	(P-d\CRCDN)
9-97	*Minor Frame		
		NUMBER OF MINOR FRAMES IN MAJOR FRAME	(P-d\MF\N)
		NUMBER OF WORDS IN A MINOR FRAME	(P-d\MF1)
		NUMBER OF BITS IN A MINOR FRAME	(P-d\MF2)
		SYNC TYPE	(P-d\MF3)
9-98		*Synchronization Pattern	
		LENGTH	(P-d\MF4)
		PATTERN	(P-d\MF5)

P Group Example

P-1\DLN:PCM1;
P-1\D1:NRZ-L;
P-1\D2:1666666;
P-1\D4:N;
P-1\TF:ONE;
P-1\F1:16;
P-1\F2:M;
P-1\F3:NO;
P-1\MF\N:4;
P-1\MF1:13;
P-1\MF2:224;
P-1\MF3:FPT;
P-1\MF4:32;
P-1\MF5:00011111011101001110100101001001;
P-1\SYNC1:0;
P-1\SYNC2:0;
P-1\SYNC3:0;
P-1\SYNC4:0;
P-1\ISF\N:1;

Linkage

Table 9-6. PCM Format Attributes Group (P)

Parameter	Code Name	Usage Attributes
DATA LINK NAME	P-d\DLN	R/R Ch 10 Status: RO
		Allowed when: defining PCM data
		Required when: Allowed
		Links from: M-x\BB\DLN, M-x\SI\DLN-n, R-x\CDLN, P-d\AEF\DLN-n, P-d\FSC2-n, P-d\ADM\DMN-n, R-x\EV\DLN-n
		Links to: D-x\DLN, B-d\DLN
		Range: 32 characters

- Is linked to from M, R, or P groups
- Links to either D or B group

D Group

Figure 9-7. PCM Measurement Description Group (D)			Code Name
DATA LINK NAME - 9-112			(D-x\DLN)
9-112	NUMBER OF MEASUREMENT LISTS		(D-x\ML\N)
	MEASUREMENT LIST NAME		(D-x\MLN-y)
	NUMBER OF MEASURANDS		(D-x\MN\N-y)
	MEASUREMENT NAME		(D-x\MN-y-n)
9-113		PARITY	(D-x\MN1-y-n)
		PARITY TRANSFER ORDER	(D-x\MN2-y-n)
		MEASUREMENT TRANSFER ORDER	(D-x\MN3-y-n)
		*Measurement Location	
9-114		MEASUREMENT LOCATION TYPE	(D-x\LT-y-n)
		*Word And Frame	
		SUBFRAME ID COUNTER NAME	(D-x\IDCN-y-n)
		NUMBER OF MEASUREMENT LOCATIONS	(D-x\MML\N-y-n)
		NUMBER OF FRAGMENTS	(D-x\MNF\N-y-n-m)
		WORD POSITION	(D-x\WP-y-n-m-e)
		WORD INTERVAL	(D-x\WI-y-n-m-e)
		FRAME POSITION	(D-x\FP-y-n-m-e)
		FRAME INTERVAL	(D-x\FI-y-n-m-e)
		BIT MASK	(D-x\WFM-y-n-m-e)
		FRAGMENT TRANSFER ORDER	(D-x\WFT-y-n-m-e)
		FRAGMENT POSITION	(D-x\WFP-y-n-m-e)
		*Simultaneous Sampling	
		SAMPLING MODE	(D-x\SS-y-n)
		SAMPLE ON	(D-x\SON-y-n)
		SAMPLE ON MEASUREMENT NAME	(D-x\SMN-y-n)
		NUMBER OF WORD FRAME SAMPLES	(D-x\SS\N-y-n)
		SAMPLE ON WORD	(D-x\SS1-y-n-s)
		SAMPLE ON FRAME	(D-x\SS2-y-n-s)

D Group Example

D-1\DLN:PCM1;
D-1\ML\N:1;
D-1\MLN-1:PIT_WDAU;
D-1\MN\N-1:45;
D-1\MN-1-1:DAYS;
D-1\MN1-1-1:DE;
D-1\MN2-1-1:D;
D-1\MN3-1-1:M;
D-1\LT-1-1:SF;
D-1\SF1-1-1:14;
D-1\SF2-1-1:4;
D-1\SFM-1-1:0000000001111111;

D-1\MN-1-2:SFID1;
D-1\MN1-1-2:DE;
D-1\MN2-1-2:D;
D-1\MN3-1-2:M;
D-1\LT-1-2:MF;
D-1\MF-1-2:1;
D-1\MFM-1-2:FW;
D-1\MN-1-3:HIG~~H~~_TIME;
D-1\MN1-1-3:DE;
D-1\MN2-1-3:D;
D-1\MN3-1-3:M;
D-1\LT-1-3:SF;
D-1\SF1-1-3:14;
D-1\SF2-1-3:1;
D-1\SFM-1-3:FW;
D-1\MN-1-4:LOW_TIME;
D-1\MN1-1-4:DE;
D-1\MN2-1-4:D;
D-1\MN3-1-4:M;
D-1\LT-1-4:SF;
D-1\SF1-1-4:14;
D-1\SF2-1-4:2;
D-1\SFM-1-4:FW;

COMMENT:=====;
COMMENT: SCD-608D-2-1-1;
COMMENT: 52318A;
COMMENT:=====;
D-1\MN-1-6:52318A;
D-1\MN1-1-6:DE;
D-1\MN2-1-6:D;
D-1\MN3-1-6:M;
D-1\LT-1-6:SF;
D-1\SF1-1-6:4;
D-1\SF2-1-6:1;
D-1\SFM-1-6:FW;

B Group

Figure 9-8. Bus Data Attributes Group (B)		Code Name
DATA LINK NAME - 9-121		(B-x\DLN)
	TEST ITEM	(B-x\TA)
	BUS PARITY	(B-x\BP)
	NUMBER OF BUSES	(B-x\NBS\N)
	BUS NUMBER	(B-x\BID-i)
	BUS NAME	(B-x\BNA-i)
	BUS TYPE	(B-x\BT-i)
	* User-Defined Words	
	USER-DEFINED WORD 1 MEASUREMENT	(B-x\UMN1-i)
	PARITY	(B-x\U1P-i)
	PARITY TRANSFER ORDER	(B-x\U1PT-i)
	BIT MASK	(B-x\U1M-i)
	TRANSFER ORDER	(B-x\U1T-i)
	USER-DEFINED WORD 2 MEASUREMENT	(B-x\UMN2-i)
	PARITY	(B-x\U2P-i)
	PARITY TRANSFER ORDER	(B-x\U2PT-i)
	BIT MASK	(B-x\U2M-i)
	TRANSFER ORDER	(B-x\U2T-i)
	USER-DEFINED WORD 3 MEASUREMENT	(B-x\UMN3-i)
	PARITY	(B-x\U3P-i)
	PARITY TRANSFER ORDER	(B-x\U3PT-i)
	BIT MASK	(B-x\U3M-i)
	TRANSFER ORDER	(B-x\U3T-i)

B/R Group Example

R-1\DSI-2:F1;
R-1\TK1-2:2;
R-1\CHE-2:T;
R-1\CDT-2:1553IN;
R-1\TK4-2:2;
R-1\CDLN-2:F1;
R-1\BTF-2:1;
B-2\DLN:F1;
B-2\NBS\N:1;
B-2\BID-1:00000000;
B-2\BNA-1:F1;
B-2\BT-1:1553;

C Group

Figure 9-10. Data Conversion Attributes Group (C)			Code Name
MEASUREMENT NAME - 9-143			(C-d\DCN)
9-143	*Transducer Information		
		TYPE	(C-d\TRD1)
		MODEL NUMBER	(C-d\TRD2)
		SERIAL NUMBER	(C-d\TRD3)
		SECURITY CLASSIFICATION	(C-d\TRD4)
		ORIGINATION DATE	(C-d\TRD5)
		REVISION NUMBER	(C-d\TRD6)
9-144		ORIENTATION	(C-d\TRD7)
	*Point of Contact		
		NAME	(C-d\POC1)
		AGENCY	(C-d\POC2)
9-144		ADDRESS	(C-d\POC3)
		TELEPHONE	(C-d\POC4)
9-144	*Measurand		
		DESCRIPTION	(C-d\MN1)
		MEASUREMENT ALIAS	(C-d\MNA)
		EXCITATION VOLTAGE	(C-d\MN2)
		ENGINEERING UNITS	(C-d\MN3)
9-144		LINK TYPE	(C-d\MN4)
	*Telemetry Value Definition		
		BINARY FORMAT	(C-d\BFM)
	*Floating Point		
		FLOATING POINT FORMAT	(C-d\FPF)
	*Bit Weight		
		NUMBER OF BITS	(C-d\BWT\N)
		BIT NUMBER	(C-d\BWTB-n)
		BIT WEIGHT VALUE	(C-d\BWTV-n)

C Group Example

```
COMMENT:=====;
COMMENT:    DCN: MN1:  SCD-608D-2-1-1;
COMMENT:          52318A;
COMMENT:=====;
C-6\DCN:52318A;
C-6\TRD1:Analog;
C-6\TRD5:05/05/15;
C-6\MNA:L VERT ACCEL;
C-6\MN1:52318A;
C-6\MN3:G;
C-6\BFM:UNS;
C-6\MOT3:65535;
C-6\MOT4:0;
C-6\COM:RAW SAMPLE;
C-6\DCT:COE;
C-6\CO\N:1;
C-6\CO:-10.3544289410518430;
C-6\CO-1:0.0003196816759300;
```